



KOAMTAC Fundamentals

Attaching a Hand Strap to a
KDC400 Series *SMARTSLED*

KOAMTAC Fundamentals

Attaching a Hand Strap to a KDC400 Series *SMARTSLED*

Identify the mounting locations on the back of your SMARTSLED. These locations will be the four corners of the SMARTSLED, as shown below.



Detach both clasps from your hand strap & choose which hand your will be using with your hand strap.



KOAMTAC Fundamentals

Attaching a Hand Strap to a KDC400 Series *SMARTSLED*

To hold with your RIGHT hand, insert the detached elastic bands into corners B & C.
To hold with your LEFT hand, insert the detached elastic bands into corners A & D.

After making your selection, insert the detached elastic bands, pulling the elastic band to make a knot around the small hole. Reinsert the straps to both clasps and place your hand through the strap, adjusting accordingly.

