

KOAMTAC Finger Trigger Glove Sizing Guide

Get started with hands-free scanning by finding the right size Finger Trigger Glove for you.

- ▶ The Finger Trigger Glove is hand-specific; begin by selecting which hand you will use to scan.
- ▶ Measure the distance between the inside of your index finger and the inside of your little finger (where the bands sit for comfortability). (A)
- ▶ Measure the distance from the first bend in your index finger to the bend of your wrist. (B)
- ▶ Measure the circumference of your wrist. (C)

The wrist strap is adjustable and should fit loosely - it can be tightened or loosened slightly more. Finger strap circumferences provided for information purposes only — they are made of adjustable leather.

Compare the measurements with the chart below to find the closest match for you!



Finger Trigger Glove Size	A	B	Wrist Circumference	Index Finger Circumference	Little Finger Circumference
Small	42mm	100mm	190mm - 250mm max	70mm - 80 mm max	60mm - 70mm max
Medium	49.7mm	110mm	195mm - 250mm max	70mm - 80mm max	60mm - 70mm max
Large	64mm	136mm	200mm - 250mm	70mm - 80mm max	60mm - 70mm max